

Підключення роутерів D-Link, Tplink.

1. Заходимо на головну сторінку вашого роутера. В більшості випадків це буде адреса <http://192.168.1.1> , але ліпше переконались в інструкції для вашого пристрою.
Логін та пароль по замовчанню для нового пристрою – admin/admin (якщо не пускає, дивись інструкцію).
2. Відкриваємо пункт меню «Мережа» або «Сеть» або «Network», в залежності від встановленої у вас мови.
На роутері D-Link відкриваємо підпункт WAN, заповнюємо 3 поля:
 - Тип з'єднання – обираємо **PPPoE**
 - Ім'я користувача (те, що надав провайдер при підключенні)
 - Пароль (те, що надав провайдер при підключенні)Решту приводимо до вигляду, як на картинці нижче.
3. Натискаємо зберегти, користуємося.

Ще радимо зайти в пункт меню «Безпека» та змінити пароль користувача admin. Щоб його не забути та не загубити, запишіть його на папірець та приклейте скотчем на роутер знизу.

Для роутера TP-link все так само, тільки картинка буде трошки інакша:

The screenshot shows the web management interface for a TP-Link Archer C50 router. The top header is teal and contains the TP-Link logo, the product name "Двухдиапазонный беспроводной маршрутизатор AC1200", and the model "Модель Archer C50". A left sidebar menu lists various settings, with "Сеть" (Network) highlighted in yellow. The main content area is titled "WAN" and displays the configuration for the WAN connection. The "Тип подключения" (Connection type) is set to "PPPoE". The "PPP имя пользователя" (PPP username) field is masked with black dots. The "PPP пароль" (PPP password) and "Подтвердить пароль" (Confirm password) fields are also masked. The "Вторичное подключение" (Secondary connection) section has "Отключено" (Disabled) selected. The "IP-адрес" (IP address) is "0.0.0.0" and the "Маска подсети" (Subnet mask) is "0.0.0.0". There are "Обновить" (Refresh) and "Освободить" (Release) buttons. The "Режим подключения" (Connection mode) has "Всегда активно" (Always on) selected. The "Максимальное время простоя" (Maximum idle time) is set to 15 minutes. The "Тип аутентификации" (Authentication type) is set to "АВТО_АУТЕН" (Auto-authentication). There are "Подключить" (Connect) and "Отключить" (Disconnect) buttons at the bottom.